

🕳 Sample &

Buy



bq500414Q

ZHCSCA4B - JANUARY 2014 - REVISED JUNE 2014

Support &

Community

....



Technical

Documents

特性 1

- 使用三个线圈发射阵列的扩展自由定位
- 符合汽车应用要求的 AEC-Q100 标准
- 符合无线电源联盟 (WPC) A6 发射器类型技术规范
- Ⅰ²C 接口用于实现控制以及与主机控制器通信,即 读取 Tx 和 Rx 状态, 启动 Tx 和变换 Tx 工作频率
- WPC v1.1 兼容,其中包括经改进的外来物体检测 (FOD) 方法
- 针对 WPC v1.0 接收器保护的增强型寄生金属物体 检测 (PMOD)
- 数字解调减少了组件数量
- 过流保护
- 充电状态和故障状态的 LED 指示

2 应用范围

- WPC 1.1 无线充电器: •
 - 汽车和其他车辆配件内的应用
 - 符合 Qi 标准的智能手机和其它手持设备
 - 工业和医疗应用

简化图表

4

TI 无线充电解决方案的更多信息,请 见www.ti.com.cn/wirelesspower

3 说明

Tools &

Software

bq500414Q 是一款符合 AEC-Q100 标准的自由定位数 字无线电源控制器,此控制器设计用于汽车应用。 它 集成了无线电源至 WPC 兼容接收器传输控制所需的全 部功能。 它可使用 WPC v1.1 版本,并且针对 12V 系 统而设计;然而,bq500414Q适用于其他电源电压。 bq500414Q 询问周围环境中将被充电的 WPC 兼容器 件。一旦检测到 WPC 兼容器件, bq500414Q 会立即 从被充电器件读取数据包反馈并管理电源传输。 70mm x 20mm 的充电区域在一个发射器垫上提供灵活 的接收器放置位置。 bq500414Q 通过持续监视系统已 发出和已接收的功率来支持寄生金属物体检测 (PMOD) 和外来物体检测 (FOD),从而保护器件不会出现过热 问题。如果在电源传输期间有任何异常情况发 生, bq500414Q 对其进行处理并提供故障指示器输 出。综合保护特性提供稳健耐用设计以保护所有接收 器放置位置情况下的系统。

bq500414Q 采用节省空间的 48 引脚, 7mm x 7mm 超薄型四方扁平无引线 (VQFN) 封装,运行温度范围 介于 -40℃ 至 85℃ 之间。

器件信息(1)

器件名称	封装	封装尺寸			
bq500414Q	VQFN (48)	7mm x 7mm			

(1) 要了解所有可用封装,请见数据表末尾的可订购产品附录。

SEPIC 3.3V SW HB Power Stage HB CAN or LIN Controller BQ500414Q Power Stage HB Power Stage





目录

1	特性	
2	应用	范围1
3	说明	1
4	简化	图表1
5	修订	历史记录 2
6	Pin	Configuration and Functions 3
7	Spe	cifications5
	7.1	Absolute Maximum Ratings5
	7.2	Handling Ratings5
	7.3	Recommended Operating Conditions 6
	7.4	Thermal Information 6
	7.5	Electrical Characteristics7
	7.6	Typical Characteristics 8
8	Deta	ailed Description
	8.1	Overview
	8.2	Functional Block Diagram 9

5 修订历史记录

2

Changes from Original (January 2014) to Revision A

•	已将预览文档更新为完整版。	 1
		-

Changes from Revision A (March 2014) to Revision B

•	己删除 关于无线电源联盟 (WPC) A19 和 A21 发射器类型技术规范的全部参考内容。	1
•	已更改 增强型寄生金属物体检测 (PMOD) 要点	1
•	已更改 bq500414Q 说明。	1
•	Changed Pin Functions Table EMI_SHIELD pin from O to I.	4
•	Changed Pin Functions Table COIL_SEL pin from I/O to I	4
•	Changed JEDEC document JEP157 Handling Ratings note.	5
•	已更改 Foreign Object Detection (FOD) and Parasitic Metal Object Detect (PMOD) Calibration description	. 13
•	已更改 Over-Current Protection description	. 16
•	已更改 Over-Voltage Protection section	. 16

	8.3	Feature Description	10
	8.4	Device Functional Modes	17
9	Арр	lications and Implementation	19
	9.1	Application Information	19
	9.2	Typical Application	19
10	Pow	ver Supply Recommendations	23
11	Lay	out	23
	11.1	Layout Guidelines	23
	11.2	Layout Example	24
12	器件	和文档支持	27
	12.1	器件支持	27
	12.2	商标	27
	12.3	静电放电警告	27
	12.4	术语表	27
13	机械	封装和可订购信息	27



Page

Page

www.ti.com.cn



6 Pin Configuration and Functions



bq500414Q ZHCSCA4B – JANUARY 2014– REVISED JUNE 2014

www.ti.com.cn

NSTRUMENTS

Texas

Pin Functions

PIN					
NAME	NUMBER	I/O	DESCRIPTION		
COIL_PEAK	1	Ι	Input from peak detect circuit		
T_SENSE	2	I	Sensor input. Device shuts down when below 1 V. If not used, keep above 1 V by simply connecting to 3.3-V supply		
Unused	3	I	This pin can be either connected to GND or left open. Connecting to GND can improve layout grounding		
Unused	4	I	This pin can be either connected to GND or left open. Connecting to GND can improve layout grounding		
RESET	5	I	Device reset. Use 10-k Ω to 100-k Ω pull-up resistor to 3.3-V supply		
PMOD	6	0	Select for PMOD threshold		
LED_A	7	0	Connect to a LED via 470- Ω resistor for status indication. Typically GREEN		
LED_B	8	0	Connect to a LED via 470- Ω resistor for status indication. Typically RED		
LED_C	9	0	Connect to a LED via 470- Ω resistor for status indication. Typically YELLOW		
PMB_CLK	10	I/O	10-kΩ pull-up resistor to 3.3-V supply. I ² C Clock		
PMB_DATA	11	I/O	10-kΩ pull-up resistor to 3.3-V supply. I ² C Data		
DPWM_A	12	0	PWM Output to half bridge driver. Switching dead times must be externally generated		
FOD	13	0	Select for FOD threshold		
Unused	14	0	Reserved, leave this pin open		
COIL 1.1	15	0	Enables the first coil drive train and COMM signal selector		
COIL 1.2	16	0	Enables the second coil drive train and COMM signal selector		
COIL 1.3	17	0	Enables the third coil drive train and COMM signal selector		
EN_PWR	18	I/O	Enable signal to the front end converter. Select the active or passive wake-up state		
RESERVED	19	0	Reserved, leave this pin open		
RESERVED	20	I	Reserved, connect to GND		
EMI_SHIELD	21	I	Connect to 3.3-V supply to indicate EMI shield is in use. If not, connect this pin to GND		
FOD_CAL	22	0	FOD Calibration		
BUZ_AC	23	0	AC buzzer output. A 400-ms, 4-kHz AC pulse train when charging begins		
BUZ_DC	24	0	DC buzzer output. A 400-ms DC pulse when charging begins. This could also be connected to an LED via $470-\Omega$ resistor		
COIL_SEL	25	Ι	Coil type select. Connect to GND for A6 typle Tx		
RESERVED	26	I/O	Reserved, connect to GND		
RESERVED	27	I/O	Reserved, leave this pin open		
RESERVED	28	I/O	Reserved, leave this pin open		
RESERVED	29	I/O	Reserved, leave this pin open		
RESERVED	30	I/O	Reserved, leave this pin open		
RESERVED	31	I/O	Reserved, connect 10-k Ω pull-down resistor to GND. Do not leave open		
GND	32	_	GND		
V33D	33	_	Digital Core 3.3-V supply. Be sure to decouple with bypass capacitors as close to the part as possible		
V33A	34	_	Analog 3.3-V supply. This pin can be derived from V33D supply, decouple with 22- Ω resistor and additional bypass capacitors		
BPCAP	35		Bypass capacitor for internal 1.8-V core regulator. Connect bypass capacitors to GND and to 3.3-V $$		
GND	36	_	GND		
COMM_A+	37	I	Digital demodulation noninverting input A, connect parallel to input B+		
COMM_A-	38	I	Digital demodulation inverting input A, connect parallel to input B-		
COMM_B+	39	I	Digital demodulation noninverting input B, connect parallel to input A+		
COMM_B-	40	I	Digital demodulation inverting input B, connect parallel to input A-		
RESERVED	41	I	Reserved, leave this pin open		



Pin Functions (continued)

PIN		1/0	DESCRIPTION		
NAME	NUMBER	1/0	DESCRIPTION		
I_SENSE	42	Ι	Transmitter input current, used for parasitic loss calculations. Use 40-m Ω sense resistor and A = 50 gain current sense amp		
LOSS_THR	43	Ι	Input to program FOD/PMOD thresholds and FOD_CAL correction		
LED_MODE	44	Ι	LED Mode Select		
V_SENSE	45	Ι	Transmitter power train input voltage, used for FOD and Loss calculations.		
Unused	46	I	This pin can be either connected to GND or left open. Connecting to GND can improve layout grounding		
GND	47	_	GND		
ADCREF	48	Ι	External reference voltage input. Connect this input to GND.		
EPAD	49		Flood with copper GND plane and stitch vias to PCB internal GND plane		

7 Specifications

7.1 Absolute Maximum Ratings⁽¹⁾

over operating free-air temperature range (unless otherwise noted)

	MIN	MAX	UNIT
Voltage applied at V33D to DGND	-0.3	3.6	
Voltage applied at V33A to AGND	-0.3	3.6	V
Voltage applied to any pin ⁽²⁾	-0.3	3.6	

Stresses beyond those listed under *absolute maximum ratings* may cause permanent damage to the device. These are stress ratings only and functional operation of the device at these or any other conditions beyond those indicated under *recommended operating conditions* is not implied. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.
All voltages referenced to GND.

7.2 Handling Ratings

		MIN	MAX	UNIT
T _{stg}	Storage temperature range	-40	150	°C
V _(ESD) ⁽¹⁾	Human-Body Model (HBM) ⁽²⁾	2	2	kV
	Charged-Device Model (CDM) ⁽³⁾	750	750	kV

(1) Electrostatic discharge (ESD) to measure device sensitivity and immunity to damage caused by assembly line electrostatic discharges in to the device.

(2) Level listed above is the passing level per ANSI, ESDA, and JEDEC JS-001. JEDEC document JEP155 states that 500-V HBM allows safe manufacturing with a standard ESD control process.

(3) Level listed above is the passing level per EIA-JEDEC JESD22-C101. JEDEC document JEP157 states that 250-V CDM allows manufacturing without risk of damaging the device with a standard ESD control process.

ZHCSCA4B-JANUARY 2014-REVISED JUNE 2014

7.3 Recommended Operating Conditions

over operating free-air temperature range (unless otherwise noted)

		MIN	NOM	MAX	UNIT
V	Supply voltage during operation, V33D, V33A	3.0	3.3	3.6	V
T _A	Operating free-air temperature range	-40		85	°C
TJ	Junction temperature			85	C

7.4 Thermal Information

		bq500414Q	
	THERMAL METRIC ⁽¹⁾	RGZ 48 PINS	UNIT
$R_{ extsf{ heta}JA}$	Junction-to-ambient thermal resistance	27.1	
R _{0JC(top)}	Junction-to-case (top) thermal resistance	12.9	
$R_{\theta JB}$	Junction-to-board thermal resistance	4.3	°C 1.1/
Ψյτ	Junction-to-top characterization parameter	0.2	C/VV
Ψ _{JB}	Junction-to-board characterization parameter	4.3	
R _{0JC(bot)}	Junction-to-case (bottom) thermal resistance	0.6	

(1) For more information about traditional and new thermal metrics, see the IC Package Thermal Metrics application report, SPRA953.



7.5 Electrical Characteristics

over operating free-air temperature range (unless otherwise noted)

	PARAMETER	TEST CONDITIONS	MIN	NOM	MAX	UNIT		
SUPPLY CURR	SUPPLY CURRENT							
I _{V33A}		V33A = 3.3 V		8	15			
I _{V33D}	Supply current	V33D = 3.3 V		44	55	mA		
I _{Total}	-	V33D = V33A = 3.3 V		52	60			
INTERNAL REG	GULATOR CONTROLLER INPUTS/OUTPUTS	1						
V33	3.3-V linear regulator	Emitter of NPN transistor	3.25	3.3	3.6	N/		
V33FB	3.3-V linear regulator feedback			4	4.6	v		
I _{V33FB}	Series pass base drive	V _{IN} = 12 V; current into V33FB pin		10		mA		
Beta	Series NPN pass device		40					
EXTERNALLY	SUPPLIED 3.3 V POWER							
V33D	Digital 3.3-V power	$T_A = 25^{\circ}C$	3		3.6			
V33A	Analog 3.3-V power	$T_A = 25^{\circ}C$	3		3.6	v		
V33Slew	3.3-V slew rate	3.3-V slew rate between 2.3 V and 2.9 V, V33A = V33D	0.25			V/ms		
DIGITAL DEMO	DULATION INPUTS: COMM_A+, COMM_A-, CO	DMM_B+, COMM_B-						
V _{CM}	Common mode voltage each pin		-0.15		1.631	V		
COMM+, COMM-	Modulation voltage digital resolution			1		mV		
R _{EA}	Input Impedance	Ground reference	0.5	1.5	3	MΩ		
IOFFSET	Input offset current	1-kΩ source impedance	-5		5	μA		
ANALOG INPU	TS: V_IN, V_SENSE, I_SENSE, T_SENSE, LED	MODE, LOSS_THR						
V _{ADC_OPEN}	Voltage indicating open pin	LED_MODE, LOSS_THR open	2.37					
V _{ADC_SHORT}	Voltage indicating pin shorted to GND	LED_MODE, LOSS_THR shorted to ground			0.36	V		
V _{ADC_RANGE}	Measurement range for voltage monitoring	ALL ANALOG INPUTS	0		2.5			
INL	ADC integral nonlinearity		-2.5		2.5	mV		
l _{lkg}	Input leakage current	3 V applied to pin			100	nA		
R _{IN}	Input impedance	Ground reference	8			MΩ		
C _{IN}	Input capacitance				10	pF		
DIGITAL INPUT	IS/OUTPUTS							
V _{OL}	Low-level output voltage	I _{OL} = 6 mA , V33D = 3 V			DGND1 + 0.25			
V _{OH}	High-level output voltage	I _{OH} = -6 mA , V33D = 3 V	V33D - 0.6 V			V		
V _{IH}	High-level input voltage	V33D = 3 V	2.1		3.6			
VIL	Low-level input voltage	V33D = 3.5 V			1.4			
I _{OH} (MAX)	Output high source current				4			
I _{OL} (MAX)	Output low sink current				4	mA		
SYSTEM PERF	SYSTEM PERFORMANCE							
V _{RESET}	Voltage where device comes out of reset	V33D pin			2.4	V		
t _{RESET}	Pulse width needed for reset	RESET pin	2			μs		
f _{SW}	Switching Frequency		120		205	kHz		
t _{detect}	Time to detect presence of device requesting power				0.5	S		

bq500414Q ZHCSCA4B – JANUARY 2014 – REVISED JUNE 2014



www.ti.com.cn

7.6 Typical Characteristics





8 Detailed Description

8.1 Overview

The principle of wireless power transfer is simply an open cored transformer consisting of transmitter (Tx) and receiver (Rx) coils. The transmitter coil and electronics are typically built into a charger pad and the receiver coil and electronics are typically built into a portable device, such as a cell-phone.

When the receiver coil is positioned on the transmitter coil, magnetic coupling occurs once the transmitter coil is driven. The flux is coupled into the secondary coil which induces a voltage and current flows. The secondary voltage is rectified, and power can be transferred effectively to a load, wirelessly. Power transfer can be managed through any of various familiar closed-loop control schemes.

The bq500414Q sends an analog ping to detect the presence of a receiver on the pad. An external enable trigger or proximity detector can also be used to provide the means of detecting the presence of a receiver. The detector can output an enable signal to the regulator supplying the bq500414Q and the device powers up, or the enable signal can start the Tx via I²C command. Once the bq500414Q is active, it pings the three coils sequentially to detect and power up the Rx. Once the Rx is powered up, it sends the communication packages to the Tx. The package information can be fetched by the Tx through demodulating the COMM feedback signal, which is a scaled version of primary coil voltage. The COMM feedback signal is multiplexed through analog switches and is synchronized to the coil being driven. To select the best coil match, the bq500414Q looks for the strongest COMM signal. Note that only one coil is driven at a time. The driven coil is tolerant of slight misalignment of the Rx while power is being transferred. Actually displacing the Rx to an adjacent coil while charging is allowable, the sequential ping sequence and detection to determine the best matching coil to drive continues to repeat. bq500414Q provides I²C interface to support some read and write commands, which can also be used to start the Tx and temporarily shift the Tx operating frequency.

8.2 Functional Block Diagram





8.3 Feature Description

8.3.1 A6 Coil Specification

bq500414Q supports WPC A6 transmitter type. The coil and matching capacitor specification for the A6 transmitter has been established by WPC standard. This is fixed and cannot be changed on the transmitter side.

The bq500414Q is primarily intended to drive a 3 coil array but it can also be used to drive a single coil or two coils. For single coil operation, the other coils and associated electronics are simply omitted.

Schematics and BOM can be found on the product folder at www.ti.com.

For a current list of coil vendors please see:

• bqTESLA Transmitter Coil Vendors, SLUA649

8.3.2 EMI Shield

TI recommends using a PCB based Electromagnetic Interference (EMI) shield to improve the EMI performance. The shield needs to be grounded. Pin 21 is used to indicate if EMI shield is in use. See product folder at www.ti.com for additional information on reference designs and applications.

8.3.3 I²C Interface

The bq500414Q supports read and write commands via I²C, as well as firmware upgrade. This could help the host controller monitor system information, control output power, and temporarily shift the Tx operating frequency.

The slave address assigned to the bq500414Q has been hardcoded to 20 (decimal). The hardware can support 100-kHz, 400-kHz, or 1-MHz I²C operation. Contact Texas Instruments for additional information on I²C interface.

8.3.4 Active or Passive Wake-up State

At power up, the bq500414Q will read EN_PWR pin voltage. If it is low, the bq500414Q device will be in active wake-up state. It will send a analog ping to detect if a compatible Rx is present and then sends a digital ping to power up the Rx. If the EN_PWR pin voltage is high, the bq500414Q will be in a passive wake-up state and considers that the SHUTDOWN command is issued. It will not send any analog ping or digital ping to detect the presence Rx, until the SHUTDOWN command is disabled through I²C. Once the SHUTDOWN command is disabled, the bq500414Q device will be in active wake-up state and send the analog ping to detect the Rx. At the same time, it drives EN_PWR pin LOW to enable the SEPIC converter. This feature enables the use of a customer defined proximity sensor.

8.3.5 Smart Key or Immobilizer Handling

The host controller may temporarily shift the bq500414Q operating frequency via I²C, when a smart key or an immobilizer is being used to avoid the interference.



Feature Description (接下页)

8.3.6 Option Select Pins

There are four option select pins (pin 18 ~EN_PWR, pin 21 EMI_SHIELD, pin 43 LOSS_THR and pin 44 LED_MODE) on the bq500414Q. All the pin voltages will be read by bq500414Q at power up.

- Pin 18 is used to indicate if the Tx should be go into active or passive wake-up state. This pin is a logic input that can be tied to 3.3-V or GND for indication. This pin is also the active LOW enable signal to the SEPIC.
- Pin 21 is used to indicate if EMI shield is in use. This pin is a logic input that can be tied to 3.3-V or GND for indication.
- Pin 43 is used to program the Loss Threshold and FOD Calibration.
- Pin 44 is used to select the LED mode of the device. At power up, a bias current is applied to pins LED_MODE and LOSS_THR and the resulting voltage is measured in order to identify the value of the attached programming resistor. For LED_MODE, the selected bin determines the LED behavior based on 表 1. For the LOSS_THR, the selected bin sets a threshold based on 表 2. See Foreign Object Detection (FOD) and Parasitic Metal Object Detect (PMOD) Calibration section for more information.



图 5. Pin 43 LOSS_THR and Pin 44 LED_MODE Connections



Feature Description (接下页)

8.3.7 LED Modes

The bq500414Q can directly drive three LED outputs (pin 7, pin 8, and pin 9) through a simple current limit resistor (typically 470- Ω), based on the mode selected. The three current limit resistors can be individually adjusted to tune or match the brightness of the LEDs. Do not exceed the maximum output current rating of the device.

The selection resistor, connected between pin 44 and GND, selects one of the desired LED indication schemes presented in 表 1.

LED	LED			OPERATIONAL STATES							
CONTROL OPTION	SELECTION RESISTOR	DESCRIPTION	LED	STANDBY	POWER TRANSFER	CHARGE COMPLETE	FAULT	FOD Warning			
			LED1, green								
Х	< 36.5 kΩ	Reserved, do not use	LED2, red	-	-	-	-	-			
			LED3, amber								
			LED1, green	Off	Blink slow ⁽¹⁾	On	Off	Off			
1	42.2 kΩ	Choice number 1	LED2, red	Off	Off	Off	On	Blink fast ⁽²⁾			
			LED3, amber	-	-	-	-	-			
			LED1, green	On	Blink slow ⁽¹⁾	On	Off	Off			
2	48.7 kΩ	Choice number 2	LED2, red	On	Off	Off	On	Blink fast ⁽²⁾			
			LED3, amber	-	-	-	-	-			
		Choice number 3	LED1, green	Off	On	Off	Blink fast ⁽²⁾	On			
3 ⁽³⁾	56.2 kΩ		LED2, red	-	-	-	-	-			
			LED3, amber	-	-	-	-	-			
		Choice number 4	LED1, green	Off	On	Off	Off	Off			
4	64.9 kΩ		LED2, red	Off	Off	Off	On	Blink fast ⁽²⁾			
			LED3, amber	-	-	-	-	-			
			LED1, green	Off	Off	On	Off	Off			
5	75 kΩ	Choice number 5	LED2, red	Off	On	Off	Off	On			
			LED3, amber	Off	Off	Off	Blink slow ⁽¹⁾	Off			
			LED1, green	Off	Blink slow ⁽¹⁾	On	Off	Off			
6	86.6 kΩ	Choice number 6	LED2, red	Off	Off	Off	On	Blink fast ⁽²⁾			
			LED3, amber	Off	Off	Off	Off	Off			
			LED1, green	Off	Blink slow ⁽¹⁾	Off	Off	Off			
7	100 kΩ	Choice number 7	LED2, red	Off	Off	On	Off	Off			
			LED3, amber	Off	Off	Off	On	Blink fast ⁽²⁾			

表 1. LED Modes

(1) Blink slow = 0.625 Hz

(2) Blink fast = 2.5 Hz

(3) The indication of the shutdown after an Negative Temperature Coefficient (NTC) event may experience a delay in the rapid LED blinking even though the power transfer has been disabled. The indication delay may persist up to as long as the entire NTC FAULT holdoff time.



8.3.8 Foreign Object Detection (FOD) and Parasitic Metal Object Detect (PMOD) Calibration

The bq500414Q supports improved FOD (WPC v1.1) and enhanced PMOD (WPC v1.0) features. Continuously monitoring input power, known losses, and the value of power reported by the Rx device being charged, the bq500414Q can estimate how much power is unaccounted for and presumed lost due to metal objects placed in the wireless power transfer path. If this unexpected loss exceeds the threshold set by the FOD or PMOD resistors, a fault is indicated and power transfer is halted. Whether the FOD or the PMOD algorithm is used is determined by the ID packet of the receiver being charged. The ultimate goal of the FOD feature is to protect misplaced metal objects from becoming hot. Reducing the loss threshold and making the system too sensitive will lead to false trips and a bad user experience. Find the balance which best suits the application. If the application requires disabling one function or the other (or both), it is possible by leaving the respective FOD/PMOD pin open. For example, to selectively disable the PMOD function, PMOD (pin 6) should be left open.

			注		
Disabling FOD	results in a	Tx solution	that is not	WPC 1.1	Compliant

Resistors of 1% tolerance should be used for a reliable selection of the desired threshold. The FOD and PMOD resistors (pin 13 and pin 6) program the permitted power loss for the FOD and PMOD algorithms respectively. The FOD_CAL resistor (pin 22), can be used to compensate for any load dependent effect on the power loss. Using a calibrated FOD reference receiver with no foreign objects present, the FOD_CAL resistor should be selected such that the calculated loss across the load range is substantially constant (within ~100-mW). After correcting for the load dependence, the FOD and PMOD thresholds should be re-set above the resulting average by approximately 400-mW in order for the transmitter to satisfy the WPC requirements on tolerated heating.

Contact Texas Instruments for the Tx Tuning Tool to set appropriate FOD, PMOD, and FOD_CAL resistor values for your design.

BIN NUMBER	RESISTANCE (kΩ)	LOSS THRESHOLD (mW)			
0	< 36.5	250			
1	42.2	300			
2	48.7	350			
3	56.2	400			
4	64.9	450			
5	75.0	500			
6	86.6	550			
7	100	600			
8	115	650			
9	133	700			
10	154	750			
11	178	800			
12	205	850			
13	> 237	Feature Disabled			

表 2. Option Select Bins

8.3.9 Shut Down via External Thermal Sensor or Trigger

Typical applications of the bq500414Q do not require additional thermal protection. This shutdown feature is provided for enhanced applications and is not limited to thermal shutdown. The key parameter is the 1.0-V threshold on pin 2 T_SENSE. Voltage below 1.0-V on pin 2 causes the device to shut down.

The application of thermal monitoring via a Negative Temperature Coefficient (NTC) sensor, for example, is straightforward. The NTC forms the lower leg of a temperature dependant voltage divider. The NTC leads are connected to the bq500414Q device, pin 2 and GND. The threshold on pin 2 is set to 1.0 V, below which the system shuts down and a fault is indicated (depending on LED mode chosen).

To implement this feature follow these steps:

- 1. Consult the NTC datasheet and find the resistence vs temperature curve.
- 2. Determine the actual temperature where the NTC will be placed by using a thermal probe.
- 3. Read the NTC resistance at that temperature in the NTC datasheet, that is R_NTC.
- 4. Use the following formula to determine the upper leg resistor (R_Setpoint): R_Setpoint = $2.3 \times R_NTC$

The system restores normal operation after approximately five minutes or if the receiver is removed. If the feature is not used, this pin must be pulled high.

注 Pin 2 T SENSE must always be terminated, otherwise erratic behavior may occur.

AGND

AGND

图 6. Negative Temperature Coefficient (NTC) Application



(1)



8.3.10 Fault Handling and Indication

The following is a table of End Power Transfer (EPT) packet responses, fault conditions, and the duration how long the condition lasts until a retry in attempted. The LED mode selected determines how the LED indicates the condition or fault.

CONDITION	DURATION ⁽¹⁾ (BEFORE RETRY)	HANDLING
EPT-00	Immediate ⁽²⁾	Unknown
EPT-01	5 seconds	Charge complete
EPT-02	Infinite	Internal fault
EPT-03	5 minutes	Over temperature
EPT-04	Immediate ⁽²⁾	Over voltage
EPT-05	Immediate ⁽²⁾	Over current
EPT-06	Infinite	Battery failure
EPT-07	Not applicable	Reconfiguration
EPT-08	Immediate ⁽²⁾	No response
OVP (over voltage)	Immediate ⁽²⁾	
OC (over current)	1 minute	
NTC (external sensor)	5 minutes	
PMOD/FOD warning	12 seconds	10 seconds LED only, 2 seconds LED + buzzer
PMOD/FOD	5 minutes	

表 3. Fault Handling and Indication

- (1) After a FAULT, the magnetic field is re-characterized in order to improve the ability to detect the removal of the at-fault receiver. If the receiver is removed in the first second immediately following the detection of this fault (before the re-characterization is complete), the field corresponding to an empty pad may be associated with the faulty receiver and the LED indication may continue to indicate a fault state even though no receiver is present. This indication will persist until either the HOLDOFF time expires or a new receiver disturbs the field, at which time normal operation, with proper LED indication, will be resumed.
- (2) Immediate is less than 1 second.

bq500414Q

ZHCSCA4B-JANUARY 2014-REVISED JUNE 2014



www.ti.com.cn

8.3.11 Power Transfer Start Signal

The bq500414Q features two signal outputs to indicate that power transfer has begun. Pin 23 BUZ_AC outputs a 400-ms duration, 4-kHz square wave for driving low cost AC type ceramic buzzers. Pin 24 BUZ_DC outputs logic high, also for 400-ms, which is suitable for DC type buzzers with built-in tone generators, or as a trigger for any type of customized indication scheme. Do not exceed 4-mA loading from either of these pins which is more than adequate for small signaling and actuation. If not used, these pins should be left open.

8.3.12 Power-On Reset

The bq500414Q has an integrated Power-On Reset (POR) circuit which monitors the supply voltage and handles the correct device startup sequence. Additional supply voltage supervisor or reset circuits are not needed.

8.3.13 External Reset, RESET Pin

The bq500414Q can be forced into a reset state by an external circuit connected to the RESET pin. A logic low voltage on this pin holds the device in reset. For normal operation, this pin is pulled up to 3.3-V supply with a 10- $k\Omega$ pull-up resistor.

8.3.14 Trickle Charge and CS100

The WPC specification provides an End-of-Power Transfer message (EPT-01) to indicate charge complete. Upon receipt of the charge complete message, the bq500414Q will change the LED indication. The exact indication depends on the LED_MODE chosen.

In some battery charging applications there is a benefit to continue the charging process in trickle-charge mode to top off the battery. There are several information packets in the WPC specification related to the levels of battery charge (Charge Status). The bq500414Q uses these commands to enable top-off charging. The bq500414Q changes the LED indication to reflect charge complete when a Charge Status message is 100% received, but unlike the response to an EPT, it will not halt power transfer while the LED indicates charge complete. The mobile device can use a CS100 packet to enable trickle charge mode.

If the reported charge status drops below 90%, normal charging indication will be resumed.

8.3.14.1 Over-Current Protection

The bq500414Q has an integrated current protection feature which monitors the input current reported by the current sense resistor and amplifier. If the input current exceeds a predetermined threshold, a fault is indicated and power transfer is halted for one minute.

If this feature is desired, the sense resistor and amplifier are required. If this feature is not desired, and WPC v1.1 compliant (FOD) is not required, the I_SENSE input pin to the bq500414Q (pin 42) should be grounded.

注 Always terminate the I_SENSE pin (pin 42), either with the output of a current monitor circuit or by connecting to ground.

8.3.15 Over-Voltage Protection

When the Rx is quickly moved from a low coupling position to a high coupling position, the rectified voltage on the Rx could get to very high before the Tx reacts to the change. Per WPC protocol, there is certain time duration between the Control Error Packages, so the Tx will not be able to react instantaneously. The bq500414Q uses a peak-detect circuit to prevent the Rx from being over-voltage.



8.4 Device Functional Modes

8.4.1 Power Transfer

Power transfer depends on coil coupling. Coupling is dependant on the distance between coils, alignment, coil dimensions, coil materials, number of turns, magnetic shielding, impedance matching, frequency, and duty cycle.

Most importantly, the receiver and transmitter coils must be aligned for best coupling and efficient power transfer. The smaller the space between the coils is, the better the coupling; however, the practical distance is set to be less than 5-mm, as defined within the WPC specification, to account for housing and interface surfaces.

Shielding is added as a backing to both the transmitter and receiver coils to direct the magnetic field to the coupled zone. Magnetic fields outside the coupled zone do not transfer power. Thus, shielding also serves to contain the fields to avoid coupling to other adjacent system components.

Regulation can be achieved by controlling any one of the coil coupling parameters. However, for WPC compatibility, the transmitter-side coils and capacitance are specified and the resonant frequency point is fixed. Power transfer is thus regulated by changing the frequency along the resonance curve from 120-kHz to 205-kHz, (that is the higher the frequency is, the lower the power). Duty cycle remains constant at 50% throughout the power band and is reduced only once 205-kHz is reached.

The WPC standard describes the dimensions, materials of the coils, and information regarding the tuning of the coils to resonance. The value of the inductor and resonant capacitor are critical to proper operation and system efficiency.

8.4.2 Communication

Communication within the WPC is from the receiver to the transmitter, where the receiver tells the transmitter to send power and how much. In order to regulate, the receiver must communicate with the transmitter whether to increase or decrease frequency. The receiver monitors the rectifier output and using Amplitude Modulation (AM), sends packets of information to the transmitter. A packet is comprised of a preamble, a header, the actual message and a checksum, as defined by the WPC standard.

The receiver sends a packet by modulating an impedance network. This AM signal reflects back as a change in the voltage amplitude on the transmitter coil. The signal is demodulated and decoded by the transmitter-side electronics and the frequency of its coil-drive output is adjusted to close the regulation loop. The bq500414Q features internal digital demodulation circuitry.

The modulated impedance network on the receiver can either be resistive or capacitive. 8 7 shows the resistive modulation approach, where a resistor is periodically added to the load, and the resulting amplitude change in the transmitter voltage. 8 8 shows the capacitive modulation approach, where a capacitor is periodically added to the load and the resulting amplitude change in the transmitter voltage.



图 7. Receiver Resistive Modulation Circuit

TEXAS INSTRUMENTS

www.ti.com.cn

Device Functional Modes (接下页)



图 8. Receiver Capacitive Modulation Circuit

8.4.3 Power Trains

The bq500414Q drives three independent half bridges. Each half bridge drives one coil from the coil set assembly. The TPS28225 is the recommended driver device for this application. It features high-side drive capability which enables the use of N-channel MOSFETs throughout. Gate-drive supply can be derived from a primitive active voltage divider. A highly regulated supply is not required to drive MOSFET gates.

8.4.4 Signal Processing Components

The COMM signal used to control power transfer is derived from the coil voltage. Each coil has its own signal processing chain. The AC coupled coil voltage is scaled down to a manageable level and biased to a 1-V offset. Series connected diodes are provided for protection from any possible transients. The three signal processing chains are then multiplexed together via analog switches. Thus, the correct signal processing chain and COMM signal used to control power transfer is from the coil being driven.



9 Applications and Implementation

9.1 Application Information

The bq500414Q device is a wireless power transmitter controller designed for automotive applications. It integrates all functions required to control wireless power transfer to a WPC v1.1 compliant receiver. There are several tools available for the design of the system. See the product folder on www.ti.com for more details. The following sections highlight some of the system design considerations.

9.2 Typical Application

The application block diagram for the transmitter is shown in \mathbb{E} 9.





Typical Application (接下页)

9.2.1 Design Requirements

9.2.1.1 Capacitor Selection

Capacitor selection is critical to proper system operation. The total capacitance value of 2×68 -nF ($2 \times (68$ -nF + 5.6-nF) in the center coil) is required in the resonant tank. This is the WPC system compatibility requirement, not a guideline.

注 A total capacitance value of 2 x 68-nF (additional 2 x 5.6-nF center coil) (C0G dielectric type, 100V rating) is required in the resonant tank to achieve the correct resonance frequency.

The capacitors chosen must be rated for at least 100 V and must be of a high quality COG dielectric (sometimes also called NP0). These are typically available in a 5% tolerance, which is adequate. The use of X7R types or below is not recommended if WPC compliance is required because critical WPC Certification Testing, such as the minimum modulation or ensured power requirements, might fail.

The designer can combine capacitors to achieve the desired capacitance value. Various combinations can work depending on market availability. All capacitors must be of COG types, not mixed with any other dielectric types.

9.2.1.2 Current Monitoring Requirements

The bq500414Q is WPC1.1 ready. In order to enable the PMOD or FOD features, current monitoring must be provided in the design.

For proper scaling of the current monitor signal, the current sense resistor should be $40\text{-}m\Omega$ and the current shunt amplifier should have a gain of 50, such as the INA213Q1. For FOD accuracy, the current sense resistor must be a quality component with 1% tolerance, at least 1/4-Watt rating, and a temperature stability of ±200 PPM. Proper current sensing techniques in the application hardware should also be observed.

9.2.1.3 All Unused Pins

All unused pins can be left open unless otherwise indicated. Please refer to the Pin Functions table. Grounding of unused pins, if it is an option, can improve PCB layout.

9.2.1.4 Input Regulators

The bq500414Q requires $3.3-V_{DC}$ to operate. A buck converter is used to step down from the automotive rail voltage, such as the TPS54040 used in this design.

The power train bridge circuitry requires 12 V, and it is fed from a SEPIC converter using the TPS40210 controller. Since the automotive rail voltage can vary widely, this acts as a type of pre-regulator.



Typical Application (接下页)

9.2.1.5 Input Power Requirements

The design works with 6-V to 16-V input voltage. A6 Tx type requires 12-V system voltage. A SEPIC converter TPS40210 is included in the design to work with 6-V to 16-V input voltage for automotive application.

9.2.2 Detailed Design Procedure

To begin the design process a few parameters must be decided upon. The design needs to know the following:

- Active or Passive Wake-up State
- EMI Shield
- LED Mode
- Number of Tx coils (1, 2, or 3)

9.2.2.1 Active or Passive Wake-up State

bq500414Q detects the pin 18 ~EN_PWR voltage at power up. If it's high, the bq500414Q will not send any analog ping to detect the Rx, until SHUTDOWN command is disabled through I^2C . A proximity sensor could be used with this feature.

9.2.2.2 EMI Shield

EMI shield can help improve EMI performance. Pin 21 EMI_SHIELD is used to indicate if EMI shield is in use.

9.2.2.3 LED mode

bq500414Q can directly drive three LED outputs (pin 7 LED_A, pin 8 LED_B, and pin 9 LED_C). Select one of the desired LED indication schemes by choosing the selection resistor connected between pin 44 LED_MODE and GND.

9.2.2.4 Number of Transmitter Coils

bq500414Q supports 1, 2, or 3 coils. Please refer to the product folder on www.ti.com for more information on the 3-coil design.

bq500414Q ZHCSCA4B – JANUARY 2014 – REVISED JUNE 2014



Typical Application (接下页)

9.2.3 Application Performance Plots

The system efficiency with A6 Tx type coil is shown in ⊠ 10. The SEPIC converter that provides 12-V causes some efficiency drop.



The frequency shift operation is shown in the Qi Sniffer capture in \mathbb{R} 10. The Rx is placed on the Tx with no load. The operating frequency is 154-kHz. Then a FREQ_SHIFT command is issued through I²C, to shift the operating frequency to 190-kHz for 50,000-ms. After requested 50,000 ms, the operating frequency goes back to its previous operating frequency, which is 154-kHz.



图 11. Qi Sniffer Capture of Frequency Shift Operation



Typical Application (接下页)

bq500414Q EVM is tested per CISPR25 EMI specification with and without the EMI shield. The measurement results show > 24-dB improvement with the EMI shield at 5-W output power.



10 Power Supply Recommendations

The device is designed to operate from an input voltage supply range between 3.0-V to 3.6-V, nominal 3.3-V. The A6 Tx type requires 12-V system voltage. TPS40210 SEPIC converter is recommend to work with 6-V to 16-V input.

11 Layout

11.1 Layout Guidelines

Careful PCB layout practice is critical to proper system operation. There are many references on proper PCB layout techniques. A few good tips are as follows:

The Tx layout requires a 4-layer PCB layout for best ground plane technique. A 2-layer PCB layout can be achieved though not as easily. Ideally, the approach to the layer stack-up has been:

- Layer 1 component placement and as much ground plane as possible
- Layer 2 clean ground
- Layer 3 finish routing
- Layer 4 clean ground

Thus, the circuitry is virtually sandwiched between grounds. This minimizes EMI noise emissions and also provides a noise free voltage reference plane for device operation.

Keep as much copper as possible. Make sure the bq500414Q GND pins and the EPAD GND power pad have a continuous flood connection to the ground plane. The power pad should also be stitched to the ground plane, which also acts as a heat sink for the bq500414Q. A good GND reference is necessary for proper bq500414Q operation, such as analog-digital conversion, clock stability and best overall EMI performance.

Separate the analog ground plane from the power ground plane and use only ONE tie point to connect grounds. Having several tie points defeats the purpose of separating the grounds.

The COMM return signal from the resonant tank should be routed as a differential pair. This is intended to reduce stray noise induction. The frequencies of concern warrant low-noise analog signaling techniques, such as differential routing and shielding, but the COMM signal lines do not need to be impedance matched.

The DC-DC buck regulator used from the 12-V input supplies the bq500414Q with 3.3-V. Typically a single-chip controller solution with integrated power FET and synchronous rectifier or outboard diode is used. Pull in the buck inductor and power loop as close as possible to create a tight loop. Likewise, the power-train, full-bridge components should be pulled together as tight as possible. See the bq500414Q EVM for an example of a good layout technique.



11.2 Layout Example

A DC-DC buck regulator is used to step down the system voltage to the 3.3-V supply to the bq500414Q. The system voltage could be 12-V, or 6-V - 16-V depending on where the buck regulator input is. With such a step-down ratio, switching duty-cycle will be low and the regulator will be mostly freewheeling. Therefore, place the freewheeling diode current loop as close to the switching regulator as possible (loop in red). Place the buck inductor and power loop as close to that as possible (loop in blue).



图 14. DC-DC Buck Regulator Layout

Make sure the bypass capacitors intended for the bq500414Q 3.3-V supply are actually bypassing these supply pins (pin 33 V33D and pin 34 V33A) to solid ground plane. This means they need to be placed as close to the device as possible and the traces must be as wide as possible.



图 15. Bypass Capacitors Layout

Make sure the bq500414Q has a continuous flood connection to the ground plane.



Layout Example (接下页)



图 16. Continuous GND Layout

Proper current sensing layout technique is very important, as it directly affects the FOD and PMOD performance. When sampling the very low voltages generated across a current sense resistor, be sure to use the so called, "Four-wire" or "Kelvin-connection" technique. This is important to avoid introducing false voltage drops from adjacent pads and copper power routes. It is common power supply layout technique.

In the below screen shot of a Texas Instruments PCB layout, the current sense resistor is R64. Notice the R18 and R15 sensing resisters are connected to the pads of R64 so there is no measurement error introduced by copper conduction losses or copper resistance temperature dependency.



Layout Example (接下页)



图 17. Current Sensing Layout

COMM+/COMM- sense lines should be run as a balanced or differential pair. The WPC packet information runs at 2-kHz, which is essential audio frequency content and this balancing reduces noise pickup from the surrounding switching power electronics. There is no need to tune or impedance-match these lines as would be the case in RF signaling.





12 器件和文档支持

12.1 器件支持

- 1. 技术, 无线电源联盟, http://www.wirelesspowerconsortium.com/
- 2. 模拟应用期刊, 《无线充电联盟标准和 TI 兼容解决方案介绍》, Bill Johns, (德州仪器 (TI) 文献编号 ZHCT117)
- 3. 数据表,《Qi 兼容无线电源发射器管理器》, (德州仪器 (TI) 文献编号 ZHCS245)
- 4. 数据表,集成无线电源接收器,符合 Qi (无线电源联盟)标准, bq51011, bq51013, (德州仪器 (TI) 文献编 号 ZHCS113)
- 5. 应用手册, 《构建一个无线电源发射器》, (德州仪器 (TI) 文献编号 SLUA635)
- 6. 应用手册,《bqTESLA发送器线圈供应商》,(德州仪器 (TI) 文献编号 SLUA649)

12.2 商标

All trademarks are the property of their respective owners.

12.3 静电放电警告

这些装置包含有限的内置 ESD 保护。存储或装卸时,应将导线一起截短或将装置放置于导电泡棉中,以防止 MOS 门极遭受静电损伤。

12.4 术语表

SLYZ022 — TI 术语表。

这份术语表列出并解释术语、首字母缩略词和定义。

13 机械封装和可订购信息

以下页中包括机械封装和可订购信息。 这些信息是针对指定器件可提供的最新数据。 这些数据会在无通知且不对本文档进行修订的情况下发生改变。 欲获得该数据表的浏览器版本,请查阅左侧的导航栏。



10-Dec-2020

PACKAGING INFORMATION

Orderable Device	Status (1)	Package Type	Package Drawing	Pins	Package Qty	Eco Plan (2)	Lead finish/ Ball material	MSL Peak Temp (3)	Op Temp (°C)	Device Marking (4/5)	Samples
							(6)				
BQ500414QRGZRQ1	NRND	VQFN	RGZ	48	2500	RoHS & Green	NIPDAU	Level-3-260C-168 HR	-40 to 110	BQ500414Q	
BQ500414QRGZTQ1	NRND	VQFN	RGZ	48	250	RoHS & Green	NIPDAU	Level-3-260C-168 HR	-40 to 110	BQ500414Q	

⁽¹⁾ The marketing status values are defined as follows:

ACTIVE: Product device recommended for new designs.

LIFEBUY: TI has announced that the device will be discontinued, and a lifetime-buy period is in effect.

NRND: Not recommended for new designs. Device is in production to support existing customers, but TI does not recommend using this part in a new design.

PREVIEW: Device has been announced but is not in production. Samples may or may not be available.

OBSOLETE: TI has discontinued the production of the device.

⁽²⁾ RoHS: TI defines "RoHS" to mean semiconductor products that are compliant with the current EU RoHS requirements for all 10 RoHS substances, including the requirement that RoHS substance do not exceed 0.1% by weight in homogeneous materials. Where designed to be soldered at high temperatures, "RoHS" products are suitable for use in specified lead-free processes. TI may reference these types of products as "Pb-Free".

RoHS Exempt: TI defines "RoHS Exempt" to mean products that contain lead but are compliant with EU RoHS pursuant to a specific EU RoHS exemption.

Green: TI defines "Green" to mean the content of Chlorine (CI) and Bromine (Br) based flame retardants meet JS709B low halogen requirements of <=1000ppm threshold. Antimony trioxide based flame retardants must also meet the <=1000ppm threshold requirement.

⁽³⁾ MSL, Peak Temp. - The Moisture Sensitivity Level rating according to the JEDEC industry standard classifications, and peak solder temperature.

⁽⁴⁾ There may be additional marking, which relates to the logo, the lot trace code information, or the environmental category on the device.

⁽⁵⁾ Multiple Device Markings will be inside parentheses. Only one Device Marking contained in parentheses and separated by a "~" will appear on a device. If a line is indented then it is a continuation of the previous line and the two combined represent the entire Device Marking for that device.

(6) Lead finish/Ball material - Orderable Devices may have multiple material finish options. Finish options are separated by a vertical ruled line. Lead finish/Ball material values may wrap to two lines if the finish value exceeds the maximum column width.

Important Information and Disclaimer:The information provided on this page represents TI's knowledge and belief as of the date that it is provided. TI bases its knowledge and belief on information provided by third parties, and makes no representation or warranty as to the accuracy of such information. Efforts are underway to better integrate information from third parties. TI has taken and continues to take reasonable steps to provide representative and accurate information but may not have conducted destructive testing or chemical analysis on incoming materials and chemicals. TI and TI suppliers consider certain information to be proprietary, and thus CAS numbers and other limited information may not be available for release.

In no event shall TI's liability arising out of such information exceed the total purchase price of the TI part(s) at issue in this document sold by TI to Customer on an annual basis.



Texas

STRUMENTS

TAPE AND REEL INFORMATION





QUADRANT ASSIGNMENTS FOR PIN 1 ORIENTATION IN TAPE



*All dimensions are nominal												
Device	Package Type	Package Drawing	Pins	SPQ	Reel Diameter (mm)	Reel Width W1 (mm)	A0 (mm)	B0 (mm)	K0 (mm)	P1 (mm)	W (mm)	Pin1 Quadrant
BQ500414QRGZRQ1	VQFN	RGZ	48	2500	330.0	16.4	7.3	7.3	1.5	12.0	16.0	Q2
BQ500414QRGZTQ1	VQFN	RGZ	48	250	180.0	16.4	7.3	7.3	1.5	12.0	16.0	Q2



www.ti.com

PACKAGE MATERIALS INFORMATION

3-Jun-2022



*All dimensions are nominal

Device	Package Type	Package Drawing	Pins	SPQ	Length (mm)	Width (mm)	Height (mm)
BQ500414QRGZRQ1	VQFN	RGZ	48	2500	356.0	356.0	35.0
BQ500414QRGZTQ1	VQFN	RGZ	48	250	210.0	185.0	35.0

RGZ 48

7 x 7, 0.5 mm pitch

GENERIC PACKAGE VIEW

VQFN - 1 mm max height

PLASTIC QUADFLAT PACK- NO LEAD



Images above are just a representation of the package family, actual package may vary. Refer to the product data sheet for package details.



RGZ0048H



PACKAGE OUTLINE

VQFN - 1 mm max height

PLASTIC QUAD FLATPACK - NO LEAD



NOTES:

- 1. All linear dimensions are in millimeters. Any dimensions in parenthesis are for reference only. Dimensioning and tolerancing per ASME Y14.5M. 2. This drawing is subject to change without notice.
- 3. The package thermal pad must be soldered to the printed circuit board for thermal and mechanical performance.



RGZ0048H

EXAMPLE BOARD LAYOUT

VQFN - 1 mm max height

PLASTIC QUAD FLATPACK - NO LEAD



NOTES: (continued)

 This package is designed to be soldered to a thermal pad on the board. For more information, see Texas Instruments literature number SLUA271 (www.ti.com/lit/slua271).

 Vias are optional depending on application, refer to device data sheet. If any vias are implemented, refer to their locations shown on this view. It is recommended that vias under paste be filled, plugged or tented.



RGZ0048H

EXAMPLE STENCIL DESIGN

VQFN - 1 mm max height

PLASTIC QUAD FLATPACK - NO LEAD



NOTES: (continued)

6. Laser cutting apertures with trapezoidal walls and rounded corners may offer better paste release. IPC-7525 may have alternate design recommendations.



重要声明和免责声明

TI"按原样"提供技术和可靠性数据(包括数据表)、设计资源(包括参考设计)、应用或其他设计建议、网络工具、安全信息和其他资源, 不保证没有瑕疵且不做出任何明示或暗示的担保,包括但不限于对适销性、某特定用途方面的适用性或不侵犯任何第三方知识产权的暗示担 保。

这些资源可供使用 TI 产品进行设计的熟练开发人员使用。您将自行承担以下全部责任:(1) 针对您的应用选择合适的 TI 产品,(2) 设计、验 证并测试您的应用,(3) 确保您的应用满足相应标准以及任何其他功能安全、信息安全、监管或其他要求。

这些资源如有变更,恕不另行通知。TI 授权您仅可将这些资源用于研发本资源所述的 TI 产品的应用。严禁对这些资源进行其他复制或展示。 您无权使用任何其他 TI 知识产权或任何第三方知识产权。您应全额赔偿因在这些资源的使用中对 TI 及其代表造成的任何索赔、损害、成 本、损失和债务,TI 对此概不负责。

TI 提供的产品受 TI 的销售条款或 ti.com 上其他适用条款/TI 产品随附的其他适用条款的约束。TI 提供这些资源并不会扩展或以其他方式更改 TI 针对 TI 产品发布的适用的担保或担保免责声明。

TI 反对并拒绝您可能提出的任何其他或不同的条款。

邮寄地址:Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2022,德州仪器 (TI) 公司